







PRODUCT REPACKAGING

POLE•WRAP®

The Best Solution for Finishing Basement Poles™

Tools Needed: Clear Packaging Tape, Ruler

09/01/2014 For assistance call 1-800-241-7653

SKU Package	Crash Kit #	How to Repackage
	CK302-073 contains 3 Packages for SKU 302-073 (Cap & Base Model 85CB30 for 3" diameter pole).	Uncollapse box and tape bottom closed. Insert folded Instruction Sheet and 3 brown boxed components (2 of 3" Cap Set and 1 of 3" Base Set). Tape top closed.
	CK302-083 contains 3 Packages for SKU 302-083 (Cap & Base Model 85CB35 for 3 1/2" diameter pole).	Uncollapse box, tape bottom closed. Insert folded Instruction Sheet, 3 brown boxed components (2 of 3 1/2" Cap Set and 1 of 3 1/2" Base Set). Tape top closed.
	CK467-735 contains 3 Packages for SKU 467-735 (Cap & Base Model 85CB40 for 4" diameter pole).	Uncollapse box and tape bottom closed. Insert folded Instruction Sheet and 3 brown boxed components (2 of 4" Cap Set and 1 of 4" Base Set). Tape top closed.
	CK475-333 3 Packages for SKU 475-333 (Wrap Model 85128 for 3" or 3 1/2" diameter pole).	Follow the instructions for Securing Wrap Label in right hand column. The correct Wrap size for this package measures 12" x 96".
	CK475-361 3 Packages for SKU 475-361 (Wrap Model 85168 for 4" diameter pole).	Follow the instructions for Securing Wrap Label in right hand column. The correct Wrap size for this package measures 16" x 96".
	CK475-363 2 Packages for SKU 475-363 (Wrap Model 85048 for multiple poles).	Follow the instructions for Securing Wrap Label in right hand column. The correct Wrap size for this package measures 48" x 96".

These repackaging instructions and the Instruction Sheet for inclusion in the product package are available to print on ePOP (Items D3019356-01 and D3019356-02).

Secure Wrap Label

Place Label against side edge of Wrap at 22 inches from the bottom edge as shown in photo below (*make sure Label is not upside down*). Place tape across both back side of Label and Wrap. Place Instruction Sheet on top and roll everything up so Label finishes on outside. Slide Wrap into poly tube and fold open end over and tape closed.

Note: Do not tape Label to front side of Wrap. Tape residue will cause wood finishing problems.

